

# COMPONENT PHOTO EYE CONF

## 1. Description

Final confirmation sensor before sort or destination.

## 2. Functions

- Verifies package reaches expected destination

## 3. I/O and Signals

Signal Name	Type	Description	Panel
PE_CONFIRM_PASS	DI	Confirmation sensor	PANEL_CONTROL_RIO

## 4. Interlocks & Safety

- Logs if confirmation not received

## 5. Dependencies

- Optional redundancy to tracking logic

## 6. Alarms

- Can trigger sort failure event

## 7. HMI / Operator Interaction

- Confirm signal logging